

SHOOTER TRAINING SYSTEMS

SCATT WM9 / WS1 / USB

USER MANUAL

SCATT company Tel: +7 (499) 504-93-74 e-mail: info@scatt.com www.scatt.com

Please read this manual to its end to secure safety and best quality of the system's operation.

© SCATT company all rights reserved.

Dear Customer, thank you for buying this system. Please read this manual to its end to secure safety and best quality of the system's operation.

Please pay your attention that SCATT USB, WS1 and WM9 systems can be used for indoor practice only.

Content

	Supplied accessories	. 4
	Software installation	7
	Electronic target installation	8
	Optical sensor OS-02 / WS-3 installation	9
	Optical sensor WS-M01 installation	. 11
	Starting SCATT	13
	Printing paper target	13
Su	New practice starting	14
<u>:</u>	Optical sensor calibration	15
a	Practice window (sighting mode).	16
B	Use electronic corrections	.17
0	Scaling the target	18
Si.	Practice window (match mode)	18
Ba	Control panel	.19
	Saving training results	21
	Opening saved result	21
	Additional features of the program	22
S	General info	.22
0	Distance curve	23
C.	Coordination curve	24
L n	Shift curve	25
4	Aiming point speed curve	.26
ě	Time intervals graph	27
aD	Probability graph	38
ž	Compare two training	30
Ă	Options menu	31
	Shots parameters menu	32
	Short keys	32
	Troubleshooting	33
	Service	.33
	Specifications	33
	Template for mounting electronic target on the wall	.35





















SCATT USB accessories	
Please check and identify all supplied accessories	V
1. Electronic target ST4-12	
2. Electronic target control unit WTC-01	
3. Optical sensor OS-02	
4. Mounting parts set	
5. Software CD	
6. User guide	
7. Electronic target control unit interface cable	
3. Electronic target interface cable	
 Optical sensor interface cable 	Γ

System installation

Software installation

Before using SCATT system, you need to install SCATT drivers and software.

Insert disk (provided in a set) in the CD-ROM drive, select SCATT. EXE icon in the disc drive window and follow instructions on the screen (fig. 1).

Install drivers before attaching SCATT devices to the computer, then attach all devices one by one.



While all necessary software is included on CD, we recommend to download latest versions of software from <u>http://www.scatt.com.</u>

System installation

Optical sensor OS-02 / WS-03 installation

Electronic target installation

Install electronic target on a tripod (photo tripod) or fix it on the wall at the distance from 3 to 6 meters for SCATT WM9 model and from 4 to 10 meters for SCATT WS1 and SCATT USB models so that the LEDs face the shooter. Insert a paper target, but make sure it doesn't cover the LEDs. Connect electronic target to USB port of your computer as shown on a scheme.



OS-02 optical sensor connection

Connect optical sensor model OS-02 to USB port of your computer by standard USB A - mini B type cable (included with your kit).



WS-03 optical sensor connection

Optical sensor has a two-way infrared connection with the electronic target. Sensor has a built-in battery and can be recharged from USB port of your computer. Full charging cycle is1.5 hours. Operating time of a fully charged battery approximately 30 hours of non-stop aiming or 10.000 shots (with an average time 10 sec. Per shot). In case of non-use, the sensor automatically switches to sleep mode.



SCATT trigger sensor (not included in the set) can be plugged into the USB connector of WS-03 optical sensor.

Clamp position adjusting

You can change clamp position on optical sensor body.

- 1 Optical sensor body
- 2 Clamp
- 3 Clamp fixing screw



Optical sensor OS-02 / WS-03 installation

Installation sensor on the barrel



Installation options:

- Mounting the optical sensor on the barrel or gas cylinders using the mounting prism and plate with screw
- Mounting the optical sensor on short barrel pistols using barrel inserts of various calibers



Installation sensor into the 9 mm barrel



Optical sensor has a two-way infrared connection with the electronic target.

Operating time from one battery (1.5V - SW 393 SR) about 10,000 shots (with an average time of sighting 3sec)*.

In case of prolonged non-use, the sensor automatically switches to sleeping mode.

Warning!

Observe the battery polarity. To avoid battery discharge, store sensor away from strong lights or direct sunlight. With long-term (more than a week) non-use the sensor, please remove the battery.

Before using the sensor, make sure the firearm **is not loaded**! Don't forget remove the sensor from barrel after training.

*To achieve the stated performance, we recommend using battery of the following manufacturers: RENATA, DURACELL, ENERGIZER, VARTA, GP. We do not recommend the use of zinc-air batteries are labeled "PR".



- 1 Optical sensor
- 2 Mounting prism
- 3 Mounting plate with screw
- 4 Barrel of a gun
- 5 Barrel insert (not included in a set)
- 6 Short barrel pistol

Optical sensor WS-M01 installation

Installation sensor on the barrel

For fixation of the optical sensor outside the barrel extra mounting parts are required (not included with your kit).



Installation options:

- Optical sensor fix on barrel (or gas cylinder) using mounting prism and plate with screw.
- Optical sensor fix on barrel using barrel inserts of various calibers.
 - 1. Optical sensor WS-M01
 - 2. Clamp S9
 - 3. Mounting prism
 - 4. Mounting plate with screw
 - 5. Barrel
 - 6. Fixing screw

Optical sensor capture area



Operating SCATT / Basic operations

Starting SCATT

When hardware and software installation is over, select SCATT icon in a program manager to start the program (fig. 2).

SCATT Professional		. 🗆 🗙
Eile Edit Shooting View	w Tools ? 🛛 🔂 Start 🚅 Open 📾 Model 🎒 🔚 🖓 Shot list 💲 Series 🛛 🛐 🙀 🄇	
SC	SHOOTHER HEALINING SYSTEMS	
Start practice	A Scatt System is a Computer aided training accessory for shooters. An extremely safe system works on a dry fire basis or can be used with air pellets and allows individual shooters to be able to physically see what happening at the end of the barrel throughout the whole shot. Not only can you see the results of your shot after it has been taken but you also have the opportunity to see what is happening while you are actually aiming at the target. The Scatt system was developed to assistores from all over the world to enable them to reach their highest goals. It helps to develop a shocter's ability to achieve very high scores in shooting competitions, which in sport shooting is the primary objective. A series of easy to understand graphs enable you to assess exactly what happened, what your problems are and the best course of action to take. Additional information Visit our web site at the address <u>www.scatt.com</u> for additional information, software updates and support	is pist
Press F1 for help		•
		Fig. 2

Printing paper target

Before starting a new training, you need to print out a paper target, corresponding to the desired distance, and exercise (program allows you simulate shooting at distances up to 1000 meters).

To print a custom paper target, connect printer to your computer and select "Print target" option in "Tools" menu of the SCATT program control panel (fig. 3).

🔏 SCA	TT Pro	fessional												
File	Edit	Shooting	View	Tools	2	🕹 Start	i ⊖ Open	Model	8	🖁 Shot list	Series	8	۲	
				Pric	nt targ	et								Fig. 0
				Re	set har	dware (Itrl+H							Fig. 3
				is Shr	ots par	ameters	,							
				B Op	tions									

Operating SCATT / Basic operations

In this window (fig. 4) you need to select the exercise (target and simulated distance) and enter the distance to electronic target and then click "Print" button. The printed target will correspond in scale with the distance to simulated target.

Cut and paste it into paper target fixators of the electronic target as shown on a scheme (see electronic target installation).



Fig. 4

New practice starting

To start training, push "Start practice" button or select "Start practice" in "File" menu. In the dialog box (fig. 5), select exercise, type name of shooter and press "Start" button.

Operating SCATT / Basic operations

Start Practice					×
Scatt connected to:	Scatt Wire	less #1			•
Shooter name:	John Smith	Shoote	r Name		•
5m Balkenscheibe ho 5m Balkenscheibe vo 5m GLOCK17 (5.6 m 5m Ovalscheibe (9.0 8m MVD (9.0 mm) 10m Air Pistol (4.5 mm 10m Air Bilank target 10m AP Blank target 10m AUG_A2 (9.0 mm)	n) (4.5 mm) mm) n) (4.5 mm) (4.5 mm) (4.5 mm)			10m Balkenscheibe horizontal (9.0 mm) 10m Balkenscheibe vertikal (9.0 mm) 10m Ovalscheibe (9.0 mm) 10m Running target (4.5 mm) Darts (1.0 mm) Konigscheibe (4.5 mm) 12m Smallbore Rifle (5.6 mm) 15m Balkenscheibe horizontal (9.0 mm) 15m Balkenscheibe vertikal (9.0 mm) 15m MVD (9.0 mm)	
.		Shoo	oter exercises	Start	Cancel
					Fig. 5

Optical sensor calibration

After you clicked on "Start" button, SCATT calibration window will open. In this window (fig. 6) you need to calibrate the optical sensor (to match the axis of the optical sensor and sights) and make necessary adjustments.

Optical sensor automatically measures the distance to the electronic target. The program allows you to automatically calibrate the sensor relative to the sighting of weapons, so there is no need to adjust the sights of weapons. Sensor automatically compensates for the "blockage" of weapons!

Optical sensor contains high frequency ceramic microphone which registers the click of your weapon triggering mechanism.

To make optical sensor calibration, aim at the target and make one blank shot. Shot-hole should be displayed inside the work area. If shot-hole does not get inside the work area, check if the sensor's axis is parralel to the axis of the barrel.

If sensor doesn't respond to trigger click (doesn't display a shot-hole), reduce the trigger response regulator value.

Attention, electronic target start with 10 second delay (this time needed to charge capacitor inside).





When calibration is completed, close window by pressing "Close" button. SCATT

program will interpret your shot-hole as center of the target form.

Window "SCATT calibration" may be opened at any time by select "Adjust Optical Sensor" in "Shooting" menu or by "F2" button pressing.

Practice window (sighting mode)

When you aim at the target, your aiming trace (movements of your aiming point) will be displayed in real time, the click of triggering mechanism registers as a shot. Program calculates shot-hole position and displays it on the target (by using aiming trace speed and ballistic coefficient).

After the shot you can replay of your aiming trajectory and shot result.

Shot list contains targets with grouped shot-holes (default grouped by 10) and information about each shot (result, aiming time, aiming trace length and etc.).

Operating SCATT / Basic operations



Use electronic corrections

You can use computer mouse to make shot-hole position correction. Move mouse pointer on the last shot-hole (it takes form of palm) and pressing left mouse button, drag the hole to the desired place (fig. 8).



We don't recommend use of electronic corrections in case the shot-holes are grouped further than the 8th ring. In this case it is best to repeat sensor calibration.

When you are satisfied with the sighting shots results, you can move to "Match" mode. Press "Match" button on the control panel.

Operating SCATT / Basic operations

Scaling the target

During training you may need to change the scale of the target is displayed on the screen. You can change the scale of the target by pressing the numbers keys (1 through 0) on your keyboard, pressed numbers correspond to the target score rings.

It is possible to change target scale by double-clicking on select score ring area, by pressing right mouse button you can reset scale.

Also you can change scale of shot list group targets by pressing "Ctrl" + "1 to 0" number buttons.

You can move on-screen area with mouse while holding down left mouse button and "Ctrl" key on your keyboard.

Also possible to increase rectangular area on the target by selecting it while holding left mouse button.

Practice window (match mode)

In "Match" mode (fig. 9) all features of program is available.



Operating SCATT / Basic operations

For ease of analysis, after shot aiming trace is drawn in different colors corresponding to various time intervals:

- Green when you start aiming
- Yellow one second before shot
- Blue 0.2 second before shot
- Red after shot

Control panel

During training shooter can control some functions of the program, using the control panel (fig. 10)



Contents of "Edit" menu (fig. 11).

💰 Joh	n Smit	h - AP10 -	5/2/20	012 1:39	9:21 F	M* - SCA	TT Pr	ofessional							
File	Edit	Shooting	View	Tools	?	🙁 Stop	*	🗃 Open	🗃 Model	8	Shot list	Series	6	'ga 🔇	
	Хн	ide shot													
		elete sightir	ng shots												Fig. 11
	D	elete all sho	ots												

Contents of "Shooting" menu (fig. 12).

💰 John Smil	:h - AP10 -	5/2/201	12 1:3	9:21 P	M* - 5Ci	ATT Pr	ofessional							
File Edit	Shooting	View	Tools	7	🙁 Stop	*	🗃 Open	🚔 Model	8	Shot list	Series	6	'ga 🔇	
	R Replay ☞ Replay	/ / all shots	;	Space										Fig. 12
	🛠 Adjust	: Optical S	Sensor.	F2										
	$\left(\begin{smallmatrix} 1\\ 0 \end{smallmatrix}\right)$ Match			F3										
	Reset	trace tar	get	Enter										
	➡ Contin	nue												
	Prone													
	Stand	ing												
	Kneeli	ng												
	🙁 Stop P	ractice												

Operating SCATT / Basic operations

In "View" menu (fig. 13) you can select display mode (simple or advanced) of the program, change menu language.

hn Smith - AP10 -	5/2/20	012 1:39:	21	PM* - SCA	TT Pr	ofessional								<u> </u>
Edit Shooting	View	Tools	7	🙁 Stop	*	🗃 Open	🚔 Model	8	Shot list	Series	6	8	۲	
	🔽 Ac	dvanced m	ode											Fin 10
	Si Sh	iot list												Fig. 13
	SS Se	ries												
	🚹 Ge	eneral info		F4										
	💋 Tr	ace		F5										
	🗘 Dis	stance gra	ph	F6										
	<u>∼</u> t co	ordination	n i	F7										
	± sh	iift		F8										
	N Tr	ace Speed	1	F9										
	Tir	ne Interva	als	F10										
	Pri Pri	obability		F11										
	🗸 To	olbar												
	🗸 St	atus Bar												
	📀 Di	splay sight	ing	5										
	💋 Dis	splay all tr	ace	s										
	Dis	splay hidde	en s	shots										
	La	nguage		•										
	🔲 Fu	II Screen		F12										

Contents of "Tools" menu (fig. 14).

ohn Smith - AP10 - 5/2/2 John Smith - AP10 - 5/2/2	2012 1:39:21 PM* - SCATT Professional	<u>- I X</u>
File Edit Shooting View	Tools ? 🛛 Stop 🛠 🖆 Open 🛱 Model 🎒 🖬 🕄 Shot list 👬 Series 🛛 🛐 🙀 🄇	
	Print target Reset hardware Ctrl+H	⁻ ig. 14
	🚰 Shots parameters	

Contents of "?" menu (fig. 15).

In "Help" tab, you can get information about some aspects of the program.



Operating SCATT / Basic operations

Saving training results

SCATT program automatically save shooting results in the directory where the files are grouped under the name of exercise and names of the shooters. You also can print out training result.

Opening saved result

To open saved result slect "Open" in "File" menu of toolbar or press "Open" button. In opened window (fig. 16) select exercise, shooter name, shooting file and press "Open".

□ 10m Air Pistol (4.5 mm) □ 10m Air Pistol 0.1 mm □ 10m Air Pistol 0.1 mm	🗸 Open			×
	Image: Second Seco	Date & time	Position Sh 21	Result (199
				Þ

Fig. 16

Additional features of the program

Not only can you see the results of your shot after it has been taken but you also have the opportunity to see what is happening while you are actually aiming at the target. The Scatt system was developed to assist shooters from all over the world to enable them to reach their highest goals.

It helps to develop a shooter's ability to achieve very high scores in shooting competitions, which in sport shooting is the primary objective. A series of easy to understand graphs enable you to assess exactly what happened, what your problems are and the best course of action to take.

Some program features are not available in the "sighting" mode. To activate all features, switch program to "Match" mode.

General Info

This screen (fig. 17) shows the general information about the shooting file, as well as the loaded model. This is the place where you type in the shooter name and comment. The following items are displayed:

- Shooter name
- Comments
- Shooting event name
- Date and time of the first match shot
- The number of match shots.
- Integer result.
- Fractional result (all shots are scored as in final).
- Averaged shot result.

Result for the shot group in relation to the center of the target

Total shooting time: an interval from the beginning of first shot to the end of last shot. Average time for a shot.

Stability of time interval between each shot (if all shots are equally spread the stability is 100%).

Diametrical dispersion: a center-to-center distance between two most distant shots. Stability of aiming: average points of the tracing are taken for a given interval of time before the shot, and the diametral dispersion of these points is calculated.

Accuracy of shooting: the average point from the points described above is calculated and its distance from the center of the target is measured.

Average steadiness in 10.0: shows the amount of the final analysis (control) time up to the moment of shot release that the aiming point was within the 10.0. It is expressed in percentages.

Average length of a tracing.

Operating SCATT / Advanced functions

Elliptical factor (for shots): it is a ratio of averaged shot dispersion diameter on x-axis to that on y-axis.

Elliptical factor (for tracings): the same as above but for tracings drawn on the target.



Fig. 17

Distance curves

Distance between aiming point and the center of the target for the selected shot (fig. 18).

Three curves are drawn (vs. time) in the graph:

absolute distance from the center

distance from the center along the X-axis (axis of abscissas)

distance from the center along the Y-axis (axis of ordinates)



Operating SCATT / Advanced functions



Shift curve

In this diagram (fig. 20) the dependence of shooting result on the moment of shot release is displayed. The plot shows what the result would have been if the shot had been released at some earlier moment.

The term co-ordination (fig. 19) means the ability of the shooter to choose the optimal moment of shot release within his (her) ability of holding steadiness. This is one of the most important criteria by which the shooter's ability as a competitor can be judged. This ability to choose an optimal moment of final shot release can partly compensate for insufficient steadiness.

Co-ordination is analyzed by averaged curve of the values of $R(t) = \sqrt{X^2(t) + Y^2(t)}$, It is plotted in some time interval prior to the shot. The value of R(t), and in particular the character of the change (increase or decrease) in the final 0,2-0,3 second, are characteristic of the degree of co-ordination ability of the shooter. The faster the R(t) value grows in last 0,2 second, the lower the shooter's co-ordination ability, i.e. more likely the aiming of the rifle or pistol becomes worse in the final moment of triggering.





Aiming point speed curve

A graph of average speed of aiming point movement versus time (fig. 21).

Operating SCATT / Advanced functions



Time intervals graph

In the time diagram (fig. 22) the height of the bars represents the shot value and the distance between bars represents the time intervals between shots. This diagram shows parameters such as the stability of shooting rhythm.



Probability graph

Evaluating the effect of the rifle and cartridge (bullets) quality on shooting results (fig. 23) To test firearms and cartridges the following method is used in Russia: from a rifle fastened in a special bench 6-8 series of shots (ten shots per series) are fired. In each series of shots the distance between the centers of two most distant shot holes is determined (the Dmax10 value). The worst (maximum) value of Dmax10 of all the series of shots is considered to be characteristics of quality of the rifle and cartridges. The Dmax60 value for all 60 shots fired to the same target is the second characteristics. In accordance with this method the Dmax10 and Dmax60 values for electronic-optical training systems may be taken equal to nil. By selecting a bullet dispersion model in the program and changing the Dmax60 value in the program it is easy to estimate the effect of rifle and cartridge quality on shooting result. An opportunity to show the above method is available in the SCATT training system software. The bullets dispersion model is based on normal (Gaussian) distribution function (as a first approach), and it allows the change of Dmax60 value with small increments.

Sampling (from the model) is performed according to random law.

Operating SCATT / Advanced functions



Two displaying variants are provided. In the first one the change of overall shooting picture with recalculating the result is displayed; in the second one the probabilities of a result greater than or equal to the initial result as well as an averaged one are drawn on the diagram depending on the growth of Dmax60. In this case, for larger number of random samples taken from the dispersion model, averaged figures of the said values are taken for each of the Dmax60 values.

Analysis of curves drawn for several shooters allows you to draw some conclusions which might appear at first sight to be unexpected. Most shootings have some interval of the Dmax60 values, not equal to zero, in which there is high probability of reaching the result that is better than at Dmax60 = 0, i.e. with worse cartridges (bullets) it is possible to obtain better result than in case of ideal cartridges (bullets).

The second conclusion is that it is not always reasonable to try to use more expensive cartridges (or bullets) since in this case the expected improvement of the result may not be reached.

Compare two training

To compare two training, during analise saved shooting file, select "Open model" in "File" menu or press "Model" button on the toolbar. SCATT catalog will open. Select file for compare and press "Open" button.

Models information will be displayed on graphs by red color (fig. 24).

Model information is available on following graphs:

- Info
- Distance
- Coordination
- Shift
- Speed



Operating SCATT / Advanced functions

Options menu

In this menu (fig. 25) you can change some parameters of program.



Shots parameters menu

In this menu (fig. 26) you can change following parameters:

- Bullet dispersion changing this parameter, you can add value to the existing spread of fire to assess the result of the real picture, you can get using a bullet with a known value of the scatter
- Shot moment changing this setting you can see what would result if the shot occurred before or after a while
- F Coefficient ballistic coefficient (angular velocity multiplied by the flight time)
- · Control interval time before shoot for which analysis is based
- Coinside grouping with the center of the target trasfer center of your shot holes group to center of the target.

Shots parameters				×
Bullet dispersion		mm		
Shot moment		sec		
F Coefficient	12 -			
Control interval	1	sec		
Coinside grouping	with the cente	er of the t	arget	
	0	К	Cancel	
			F	ia 26

	Short kevs
Ctrl + N	New practice
Ctrl + O	Open file
Ctrl + P	Print practice results
Ctrl + S	Save practice results
F1	Help menu
SPACE	Replay aiming trace
F4	Info menu
F5	Target with trace
F6	Distance graph
F7	Coordination graph
F8	Shift graph
F9	Speed graph
F10	Intervals graph
F11	Probability graph
F12	Full screen mode

Software reportsMake sure all SCATT units are connected to
the computer, SCATT drivers are installed"SCATT device not fund"Either the target or optical sensor are not connected,
distance to electronic target has been selected
incorrectly. Recharge or replace optical sensor).
Check all connections, restart SCATT program.

Troubleshooting

When optical sensor enters the target area, it results in a spontaneous shot	Adjust trigger response sensitivity of optical sensor

If given recommendations don't help solve your problem, consult the Service Center.

Service

Clean this device with soft dry cloth. If the surfaces are too dirty, use soft cloth, wetted in suds or in mild soap detergent solution. Newer use solvents or petrol to clean the device.

Specifications	
Optical sensor weight:	OS-02 - 30g (with mount) WS-03 - 33g (with mount) WS-M01- 8g (with battery)
Electronic target dimensions:	H 234 x W209 x D32 mm
Type of radiation:	IR radiation of 900 nm
Operating temperature range:	+5 to +37 °C

NOTE

Specifications can be modified by manufacturer without being worded in this manual. Weight and dimensions are approximate.

Notes

130 mm.

 $\mathbf{\Phi}^{\mathbf{k}}$

 Φ



- 1

1

H